



PRODUCT CODE  
CO1605

**BATTERY INSTALLATION**


1. Hold the **Tap Timer** with the **BATTERY COMPARTMENT** facing you
2. Remove the **BATTERY COMPARTMENT** tray
3. Connect a 9V alkaline battery to the battery connector
4. Insert the connected battery and push in the **BATTERY COMPARTMENT** tray

**i** When changing a battery, the **Tap Timer** will hold the current program if you fit the battery within 2 minutes. When changing the battery, make sure the battery compartment stays dry

**i** Use only 9V alkaline batteries



**SETTING THE WATERING DAYS**



**DAYS** is where you select what day(s) you want to water on.

1. Press **ON** until the calendar is displayed on the left next to **DAYS**. This means you are in **DAYS** mode
2. Press **➡** and the black box under **M** will flash
3. Press **+** to select that day, press **-** to deselect that day
4. Press **➡** to scroll through the days, press **+** if you need to reselect that day
5. Press **ON** to save the schedule

**SUSPENDING OPERATION CONT.**

**OFF** The schedule is now suspended.

Cancel Suspension: to resume the automatic schedule press **OFF**.

Manual operation can still be used during suspension.

**TROUBLESHOOTING**

To stop manual or automatic watering press **OFF**.

**Low battery warning:** The battery indicator has 5 levels. 4 levels of battery and 1 flashing bar when the battery is flat. The **Tap Timer** will not water when the battery is in this mode. We advise to change the battery when it is down to 2 bars to ensure reliable watering.

**SETTING THE START TIMES**



**START** is the time of day you want your watering to begin. You can schedule up to 4 start times per day.

1. Press **ON** until the alarm clock is displayed in the bottom left corner next to **START**. This means you are in **START** mode
2. Start **1** is the time you want your watering to first begin. Use **+** or **-** to adjust the hour
3. Press **➡** then **+** or **-** to adjust the minutes

**FUNCTIONS**

- OFF** Press to end manual or automatic watering
- ➡** Press to scroll through the programming modes
- Press to decrease time or eliminate a day
- +** Press to increase time or add a day
- ➡** Press to select a function
- ON** Press to begin manual watering

**MAINTENANCE**

Remove the battery if the **Tap Timer** will not be used for a long period of time. The **Tap Timer** contains an internal filter which has to be removed and cleaned every few months.


**GLOSSARY**

- A. UNIVERSAL TAP ADAPTOR
- B. TAP CONNECTION
- C. UNION NUT
- D. LCD DISPLAY
- E. CONTROL BUTTONS
- F. BATTERY COMPARTMENT
- G. CLEAR SCREW-ON COVER
- H. SNAP-ON HOSE CONNECTION


**INSTALLATION**

Make sure the washer is in place, then screw the **Digital Tap Timer** to the tap. Turn it clockwise (hand tighten only).

**i** There should be no need to use thread seal tape, as long as the tap seals onto the washer




**SETTING THE CURRENT TIME**



1. Press **ON** until the clock is displayed in the top left corner next to **TIME**. This means you are in **TIME** mode
2. Press **➡** and the hour will flash
3. Press **+** or **-** to adjust the hour
4. Press **➡** to select the minutes
5. Press **+** or **-** to adjust the minutes
6. Press **➡** to select the day (the black box will be flashing)
7. Press **+** to reach the current day. Press **➡** to save the day

**SETTING THE DURATION**



**DURATION** is the length of time you want the water to run for.

1. Press **ON** until the hour glass is displayed on the left next to **DURATION**. This means you are in **DURATION** mode
2. The hour display will be flashing, press **+** or **-** to adjust the hour
3. Press **➡** to select the minutes
4. Press **+** or **-** to adjust the minutes

**MANUAL OPERATION CONT.**


1. Press **ON** to begin manual watering. The pre-set time is 10 minutes. This will start automatically unless the duration is changed
2. Manually set the duration time using **+** or **-**
3. Once the watering duration has finished the **Tap Timer** will automatically end watering and return to the automatic schedule

**SUSPENDING OPERATION**

Use this feature when you want to temporarily suspend the automatic schedule. This feature is generally used when it has been raining or during winter.

Suspension: Press **OFF** and the sprinkler off icon will appear.

**MANUAL OPERATION**



**ON** **MANUAL** allows you to manually turn on your tap timer and set a watering duration.

**i** This will not effect your automatic schedule

**TECHNICAL DATA**

- Max Water Pressure: 600kPa
- Min Water Pressure: 60kPa
- Flow Rate: 19L/min at 200kPa
- Power Source: 9 volt alkaline battery
- Power Consumption: 20 micro amps in standby mode

We recommend registering your new product to ensure we have a copy of your purchase, and to activate an extended warranty. Keep up to date with relevant product information and special offers available through our newsletter.

[www.holmanindustries.com.au/product-registration/](http://www.holmanindustries.com.au/product-registration/)

**HOLMAN**

For the #SMARTGARDENER

Head Office/Service  
11 Walters Drive, Osborne Park WA 6017  
Tel: +61 8 9416 9999 Fax: +61 8 9416 9920  
[support@holmanindustries.com.au](mailto:support@holmanindustries.com.au)  
[www.holmanindustries.com.au](http://www.holmanindustries.com.au)

Copyright © 2020 Holman Industries